



HP-35s CALCULATOR PROGRAMS

MnDOT Office of Land Management

Surveys Research & Support Unit

General Instructions for Running the Programs

The programs prompt for coordinate input and output as X and Y pairs, which correspond to E and N. All angle input and output is north-based AZIMUTH in the form D.MMSSss. Use the XEQ key, a letter label, and the ENTER key (or XEQ label 001) to run a program.

Contact

Roy Graff Phone: (651) 366-3443
 395 John Ireland Blvd, MS 643 Fax: (651) 366-3450
 Saint Paul, MN 55155-1899 E-mail: roy.graff@state.mn.us

Non-MnDOT users can expect only limited support. Please report program or listing errors.

© Minnesota Department of Transportation, 2006-2012

Warning: The user releases the Minnesota Department of Transportation from all liability resulting from inaccuracies in these application listings.

INVERSE TRAVERSE PROGRAM

XEQ I (XEQ COS ENTER)

- ↗ Enter X-Coord. of Beginning Point R/S
- ↑ Enter Y-Coord. of Beginning Point R/S
- ↑ Enter X-Coord. of Ending Point R/S
- ↑ Enter Y-Coord. of Ending Point R/S
- ↑ Read Inverse Distance R/S
- ↑ Read Inverse Azimuth (D.MMSSss) R/S
- ↩ (Next Beginning Point = This Ending Point)

AZIMUTH TRAVERSE PROGRAM

XEQ T (XEQ 9 ENTER)

- ↗ Enter X-Coord. of Beginning Point R/S
- ↑ Enter Y-Coord. of Beginning Point R/S
- ↑ Enter Azimuth to New Point (D.MMSS) R/S
- ↑ Enter Distance to New Point R/S
- ↑ Read X-Coord. of New Point R/S
- ↑ Read Y-Coord. of New Point R/S
- ↩ (Next Beginning Point = This New Point)

RADIAL INVERSE PROGRAM

XEQ R (XEQ 7 ENTER)

- Enter X-Coord. of Fixed Point R/S
- Enter Y-Coord. of Fixed Point R/S
- ↗ Enter X-Coord. of Next Point R/S
- ↑ Enter Y-Coord. of Next Point R/S
- ↑ Read Inverse Distance R/S
- ↑ Read Inverse Azimuth (D.MMSSss) R/S
- ↩ (Enter Next Radial Point)

RADIAL STUB PROGRAM

XEQ S (XEQ 8 ENTER)

- Enter X-Coord. of Fixed Point R/S
- Enter Y-Coord. of Fixed Point R/S
- ↗ Enter Azimuth to New Point (D.MMSS) R/S
- ↑ Enter Distance to New Point R/S
- ↑ Read X-Coord. of New Point R/S
- ↑ Read Y-Coord. of New Point R/S
- ↩ (Enter Next Radial Stub)

TRIANGLE PROGRAM – SSS

XEQ C (XEQ XEQ ENTER)

Enter Length of First Side	R/S
Enter Length of Second Side	R/S
Enter Length of Third Side	R/S
Read Angle Opposite & First Side	R/S
Read Angle Opposite & Second Side	R/S
Read Angle Opposite & Third Side	R/S
Read Triangle Area	R/S

TRIANGLE PROGRAM – SAA

XEQ E (XEQ R↓ ENTER)

Enter Length of First Side	R/S
Enter Angle After (DMS)	R/S
Enter Next Angle (DMS)	R/S
Read Angle Opposite & First Side	R/S
Read Angle Opposite & Second Side	R/S
Read Angle Opposite & Third Side	R/S
Read Triangle Area	R/S

TRIANGLE PROGRAM – SAS

XEQ D (XEQ MODE ENTER)

Enter Length of First Side	R/S
Enter Angle Between (DMS)	R/S
Enter Length of Second Side	R/S
Read Angle Opposite & First Side	R/S
Read Angle Opposite & Second Side	R/S
Read Angle Opposite & Third Side	R/S
Read Triangle Area	R/S

TRIANGLE PROGRAM – ASA

XEQ F (XEQ x◀▶y ENTER)

Enter Angle Before (DMS)	R/S
Enter Length of First Side	R/S
Enter Angle After (DMS)	R/S
Read Angle Opposite & First Side	R/S
Read Angle Opposite & Second Side	R/S
Read Angle Opposite & Third Side	R/S
Read Triangle Area	R/S

TRIANGLE PROGRAM – SSA

XEQ G (XEQ i ENTER)

Enter Length of First Side	R/S	
Enter Length of Second Side	R/S	
Enter Angle Opposite First Side (DMS)	R/S	
Prompt "SOLUTION 1"	R/S	{ Skip Prompt if Single Solution }
Read Angle Opposite & First Side	R/S	{ First or Single Solution }
Read Angle Opposite & Second Side	R/S	
Read Angle Opposite & Third Side	R/S	
Read Triangle Area	R/S	{ End of Program if Single Solution }
Prompt "SOLUTION 2"	R/S	
Read Angle Opposite & First Side	R/S	{ Second Solution }
Read Angle Opposite & Second Side	R/S	
Read Angle Opposite & Third Side	R/S	
Read Triangle Area	R/S	{ End of Program }

INTERSECTION PROGRAM – LL

XEQ L (XEQ y^x ENTER)

Enter X-Coord. of Point on Line 1	R/S	
Enter Y-Coord. of Point on Line 1	R/S	
Enter Azimuth of Line 1 (D.MMSSss)	R/S	{-999 to compute using a second POT}
Enter X-Coord. of Point on Line 2	R/S	
Enter Y-Coord. of Point on Line 2	R/S	
Enter Azimuth of Line 2 (D.MMSSss)	R/S	{-999 to compute using a second POT}
Read X-Coord. of Intersection	R/S	
Read Y-Coord. of Intersection	R/S	
Read Distance Point 1 to Intersection	R/S	
Read Distance Point 2 to Intersection	R/S	{End of Program}

NOTES :

This calculation is also known as a Bearing-Bearing Intersection.
Register X contains the X-Coord. of the Intersection Point
Register Y contains the Y-Coord. of the Intersection Point
Register D contains the Distance from Point 2 to the Intersection Point

INTERSECTION PROGRAM – LC

XEQ M (XEQ 1/x ENTER)

Enter X-Coord. of Point on Line	R/S	{POT}
Enter Y-Coord. of Point on Line	R/S	{POT}
Enter Azimuth of Line (D.MMSSss)	R/S	{-999 to compute using a second POT}
Enter X-Coord. of Radius Point	R/S	
Enter Y-Coord. of Radius Point	R/S	
Enter Radius of Circle	R/S	
Prompt "SOLUTION 1"	R/S	{First or Single Solution}
Read X-Coord. of Intersection 1	R/S	
Read Y-Coord. of Intersection 1	R/S	
Read Azimuth, Rad. Pt. to Intersection 1	R/S	
Read Distance, POT to Intersection 1	R/S	{End of Program if Single Solution}
Prompt "SOLUTION 2"	R/S	{Second Solution}
Read X-Coord. of Intersection 2	R/S	
Read Y-Coord. of Intersection 2	R/S	
Read Azimuth, Rad. Pt. to Intersection 2	R/S	
Read Distance, POT to Intersection 2	R/S	{End of Program}

NOTES :

This calculation is also known as a Bearing-Distance Intersection.
Register U contains the X-Coord. of Intersection Point 1
Register V contains the Y-Coord. of Intersection Point 1
Register W contains the Azimuth from the Radius Point to Intersection Point 1
Register X contains the X-Coord. of Intersection Point 2
Register Y contains the Y-Coord. of Intersection Point 2
Register Z contains the Azimuth from the Radius Point to Intersection Point 2

INTERSECTION PROGRAM – CC

XEQ N (XEQ +/- ENTER)

Enter X-Coord. of Radius Point 1	R/S	
Enter Y-Coord. of Radius Point 2	R/S	
Enter Radius of Circle 1	R/S	
Enter X-Coord. of Radius Point 2	R/S	
Enter Y-Coord. of Radius Point 2	R/S	
Enter Radius of Circle 2	R/S	
Prompt "SOLUTION 1"	R/S	{First or Single Solution}
Read X-Coord. of Intersection 1	R/S	
Read Y-Coord. of Intersection 1	R/S	
Read Azimuth, Rad. Pt. 1 to Intersection 1	R/S	
Read Azimuth, Rad. Pt. 2 to Intersection 1	R/S	{End of Program if Single Solution}
Prompt "SOLUTION 2"	R/S	{Second Solution}
Read X-Coord. of Intersection 2	R/S	
Read Y-Coord. of Intersection 2	R/S	
Read Azimuth, Rad. Pt. 1 to Intersection 2	R/S	
Read Azimuth, Rad. Pt. 2 to Intersection 2	R/S	{End of Program}

NOTES :

This calculation is also known as a Distance-Distance Intersection.
Register U contains the X-Coord. of Intersection Point 1
Register V contains the Y-Coord. of Intersection Point 1
Register J contains the Azimuth from Radius Point 1 to Intersection Point 1
Register K contains the Azimuth from Radius Point 2 to Intersection Point 1
Register X contains the X-Coord. of Intersection Point 2
Register Y contains the Y-Coord. of Intersection Point 2
Register L contains the Azimuth from Radius Point 1 to Intersection Point 2
Register M contains the Azimuth from Radius Point 2 to Intersection Point 2

RATIO PROGRAM

XEQ O (XEQ E ENTER)

Enter X-Value of Beginning Point	R/S	{Typically the first station}
Enter Y-Value at Beginning Point	R/S	{Value at start of taper, super transition, etc.}
Enter X-Value of Ending Point	R/S	{Typically the last station}
Enter Y-Value at Ending Point	R/S	{Value at end of taper, super transition, etc.}
Displays Ratio X:Y	R/S	{Goes directly into Y-Value computation}
Y-Value computation -- key XEQ E 0 1 5 to run		
Enter an increment for the X-Value	R/S	{Facilitates computation at regular intervals}
➤ X-Value at which to compute Y-Value	R/S	{Accept incremented value or enter another}
⬅ Read X-Value and computed Y-Value	R/S	{X-Value above and Y-Value below}
X-Value computation -- key XEQ E 0 2 4 to run		
➤ Y-Value for which to compute X-Value	R/S	
⬅ Read computed X-Value and Y-Value	R/S	{X-Value above and Y-Value below}

HORIZONTAL CURVE PROGRAM

XEQ H (XEQ SIN ENTER)

Required – Enter at Least One of the Following Three Fields (R/S to Skip) :

Enter the Delta Angle	R/S	{A? D.MMSS}
Enter the Degree of Curve	R/S	{D? D.MMSS – Valid for English Only}
Enter the Curve Radius	R/S	{R? English or Metric}

Optional – Enter One of the Following Fields if Needed :

Enter the Tangent Length	R/S	{T?}
Enter the Curve Length	R/S	{L?}
Enter the Chord Length	R/S	{C?}
Enter the Mid-Ordinate	R/S	{M?}
Enter the External Distance	R/S	{E?}

View the Computed Values :

Read the Delta Angle	R/S	{A= D.MMSS}
Read the Degree of Curve	R/S	{D= D.MMSS – Valid for English Only}
Read the Tangent Length	R/S	{T=}
Read the Curve Length	R/S	{L=}
Read the Curve Radius	R/S	{R=}
Read the Chord Length	R/S	{C=}
Read the Mid-Ordinate	R/S	{M=}
Read the External Distance	R/S	{E=}
Read the Sector Area	R/S	{S=}
Read the Segment Area	R/S	{G=}
Read the Fillet Area	R/S	{F=}
Enter the Station of the PI	R/S	{“PI STA”}
Read the PC and PT Stations	R/S	{End of Program}

VERTICAL CURVE (& TANGENT) PROGRAM

XEQ V (XEQ 5 ENTER)

Enter the PVI Station	R/S	{Any POT if Computing a Tangent Grade}
Enter PVI Elevation	R/S	{Any POT if Computing a Tangent Grade}
Enter the % Grade into the PVI (G1)	R/S	
Enter the % Grade out of the PVI (G2)	R/S	{= G1 if Computing a Tangent Grade}
Enter the Length of the Vertical Curve	R/S	{Zero if Computing a Tangent Grade}
Read the High or Low Point, If It Exists	R/S	{Elevation in Y- & Station in X-Registers}
Enter a Stationing Increment	R/S	{Prompt is STA INC}
↗ Enter Any Station	R/S	{Prompt is S?}
↑ Read Elevation at the Entered Station	R/S	{Display E=}
↖ Increment for Next Station		

AREA BY COORDINATES PROGRAM

XEQ A (XEQ R/S ENTER)

Enter X-Coord. of Beginning Point	R/S	
Enter Y-Coord. of Beginning Point	R/S	
↗ Enter X-Coord. of Next Point	R/S	
↑ Enter Y-Coord. of Next Point	R/S	
↖ Repeats Until Beginning Point Is Re-entered		
Read Area in Square Feet (or Meters)	R/S	{ Coordinates are assumed to be in feet. }
Read Area in Acres (Assuming Feet)	R/S	{ If units are Meters, ignore this value. }
Read Perimeter	R/S	{ End of Program }

HMS+ PROGRAM

Enter the first angle in DDD.MMSSss	ENTER
Enter the angle to add in DDD.MMSSss	XEQ P [XEQ () ENTER]
Read the sum of the angles in DDD.MMSSss	

HMS- PROGRAM

Enter the first angle in DDD.MMSSss	ENTER
Enter the angle to subtract in DDD.MMSSss	+/- XEQ P [XEQ () ENTER]
Read the difference of the angles in DDD.MMSSss	

POLAR → RECTANGULAR (y,x → θ ,r) FUNCTION

Enter the Distance	ENTER
Enter the Azimuth (D.MMSSss)	XEQ J [XEQ TAN ENTER]
Read the X-Coordinate difference	{ X-Difference in the Y-Register }
Read the Y-Coordinate difference	{ Y-Difference in the X-Register }

RECTANGULAR → POLAR (θ ,r → y,x) FUNCTION

Enter the X-Coordinate difference	ENTER
Enter the Y-Coordinate difference	XEQ K [XEQ \sqrt{x} ENTER]
Read the resulting distance	{ Distance in the Y-Register }
Read the resulting azimuth in DDD.MMSSss	{ Azimuth in the X-Register }

BEARING → AZIMUTH PROGRAM

XEQ B (XEQ GTO ENTER)

↗ Enter the Bearing to be converted	R/S	{ In DMS }
↑ Enter the Quadrant code of the bearing	R/S	{ 1 = NE, 2 = SE, 3 = SW, 4 = NW }
↖ Read the Azimuth	R/S	{ In DMS }

AZIMUTH → BEARING PROGRAM

XEQ Q (XEQ EQN ENTER)

↗ Enter the Azimuth to be converted	R/S	{ DMS }
↑ Read the Bearing	R/S	{ DMS }
↖ Read the Quadrant code of the bearing	R/S	{ 1 = NE, 2 = SE, 3 = SW, 4 = NW }